

*BPI  
Illuminated  
Lens  
Accessory  
Display*

For use only by qualified  
personnel in a  
laboratory environment.

---

## About Your BPI Accessory

The BPI Illuminated Lens Accessory Display has been specifically designed to for use within an optical laboratory or optical retail outlet.

---

## Unpacking

When unpacking your unit, please check to ensure that no concealed damage occurred in transit. If such is noted, save the shipping carton and immediately notify the shipping company's damage control inspector in your area so a claim may be processed. Failure to do this may void any future claim and replacement. Also, call BPI Customer Service so arrangements for a replacement may be made.

---

## Specifications

Your unit requires 115 volts, 60 Hz unless otherwise ordered. This unit is also available by special order in 220 volts.

---

## General Use

Place your unit on a LEVEL surface convenient to an electrical outlet. (Or secure to a wall, if you have purchased a wall-mounted accessory). Check to be sure that the fuse is in the fuse holder located at the rear of the instrument. Turn on the unit by means of the power on/off switch. In the event of any malfunction, check power outlet and fuse and then call BPI customer service.

---

## Questions?

If you have any questions about the use of your unit or need technical product information, call the BPI Research Department. For information about any other BPI product and to order supplies, please call us toll-free.